

# SM Hydraulic Pump Adjustment

*TIP: Before making adjustments, make a mark with a sharpie on the adjustment hex bolt. This will give a starting reference point.*

Loosen the Main Pressure valve 9/16" lock nut, rotate the 3/16" allen bolt clockwise 1/4 turn, repeat on the lift UP-DOWN valve. Test lift.

Repeat until lift has enough power to raise your lift pan to adequate height. Tighten lock nuts after desired result is achieved.

